



2906 West Clark Road  
 Champaign IL 61822  
 (217) 359-7680  
[www.waypointanalytical.com](http://www.waypointanalytical.com)

## Manure Sample Submittal Form

<input type="checkbox"/> Charge To <b>CUSTOMER</b>		
Name		
Address		
City	State	Zip
Email Address:		

<input type="checkbox"/> Charge To <b>COPY TO</b>		
Name		
Address		
City	State	Zip
Email Address:		

Sample ID	Test Desired (see bottom of page)				Source of Sample					Report Nutrient Concentrations As		Additional Tests
	M1	M2	M3	M4	Dairy	Swine	Poultry	Feedlot	Equine	lbs/1000 gal	lbs/ton	

Special Instructions or Comments:

<p><b>Manure Test Packages:</b>          Test M1: Moisture, Total Nitrogen, Ammonium Nitrogen, Phosphorus, Potassium          Test M2: M1 plus Sulfur, Calcium, Magnesium, Sodium, Iron, Aluminum, Manganese, Copper, Zinc, Boron          Test M3: M2 plus Cadmium, Chromium, Lead, Nickel          Test M4: M1 plus Organic Nitrogen</p>	<p><b>Additional Tests:</b>          pH                      Soluble Salts                      Individual Minerals: Cu,Fe,Mn,Zn,Na,Al,Ca,Mg,B,S          Ash                      Ammonium Nitrogen                P-Source Coefficient plus % Solids (PA Only)          Density                Carbon to Nitrogen Ratio          Chloride                Nitrate Nitrogen</p>
------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

# **Instructions for Handling and Sending Manure Samples to Waypoint Analytical**

## **Liquid Samples:**

Fill either the sample container provided by the laboratory or your own container  $\frac{1}{2}$  to  $\frac{3}{4}$  full with a representative sample. A minimum of 500 ml or roughly 2 cups of sample is preferred. Allow space in the container for expansion.

Close the lid on the container tightly and secure the lid with adhesive tape.

Place the container in a plastic Ziplock bag and seal tightly. If using a lab provided kit, use only one of the two plastic bags supplied in the manure kit.

*GLASS CONTAINERS WILL NOT BE ACCEPTED*

## **Solid Samples:**

Fill either a Ziplock bag or the sample container provided by the laboratory  $\frac{1}{2}$  to  $\frac{3}{4}$  full with a representative sample. A minimum of roughly 2 cups of sample is preferred.

Seal the container tightly and place in another plastic Ziplock bag. If using a lab provided kit, use only one of the two plastic bags supplied in the manure kit.

1. Place all paperwork associated with the testing in a plastic Ziplock bag and seal tightly.
2. Place in a box. Close and tape securely.
3. Ship or deliver the sample to our laboratory as quickly as possible to ensure the sample integrity.
4. Any questions, please call the laboratory.